

All dimensions are in millimeters

1 Door Preparation

Cut opening in door to suit cover plate and drill holes to suit function required.

Drill 2 holes
4 Dia. & C'sink
6 Dia. x 90°

Same cylinder hole detail on other side.

2 Cut Bolt Hole (Deadbolt Only)

Cut bolt hole in door jamb as shown.

3 Fit Sliding Door Strike (Hookbolt Only)

Cut opening in door jamb to suit strike plate and drill holes as shown. fit strike assembly in to door jamb and secure with 2 countersunk screws (6mm long)

4 Fit Accessories

Cylinder Assembly
Attach cylinder assembly and secure with clamp screw supplied. Ensure clamp screw is fully inserted to firmly anchor the cylinder assembly. Fit cylinder trim.

Turnknob Assembly
Attach turn knob assembly and secure with clamp screw supplied. Ensure clamp screw is fully inserted to firmly anchor turnknob assembly. Fit cylinder trim.

Cover Plate
Attach cover plate to lock with 3 countersunk head screws (5mm long) supplied.

5 Armour Plate Door Application