

Entrance set installation (steps 1 - 8)

<p>1</p> <p>Detach template from box (Pentagon)</p> <p>Door</p> <p>Centreline of door</p> <p>Mark centreline of door</p> <p>Mark position for holes</p> <p>Drill 7 Holes - 22mm Dia 90mm Deep</p> <p>Template</p> <p>Door</p>	<p>2</p> <p>Hex nuts</p>	<p>3</p> <p>Hole positions for lever assembly</p>
<p>Refer to instructions Lockwood Mortice Lock for door preparation and lock installation.</p>	<p>Entrance set Parts and assembly</p>	<p>Measure door thickness to determine the correct choice of screw length.</p>
<p>4</p> <p>48mm</p> <p>56mm</p> <p>32 - 38mm</p> <p>38 - 45mm</p>	<p>5</p> <p>Square hole in Mortice lock</p>	<p>6</p> <p>Horizontal screw holes</p>
<p>Screw lengths for door thickness.</p>	<p>Align spindle into square opening in Mortice Lock, position lever assembly so that it operates downwards to retract bolt.</p>	<p>Align and fit hex nuts into the exterior side of door through the horizontal screw holes.</p>
<p>7</p> <p>Rotate lever to fit screws</p>	<p>8</p> <p>Position removal tab to the bottom</p> <p>Removal tab</p>	
<p>Align screws through interior side of door. Fasten lever furniture to both sides of door with screws and hex nuts.</p>	<p>Position cover plate escutcheons firmly over the furniture. Position removal tab to the bottom.</p>	